







- 51 1557
I1
Gebrauchsanweisung
(D,F,I,NL,E)
51 2277
Aufstellanleitung
1) 04 2085
2) 01 9177
Set
3) 05 0504



- 1) 08 0781 Set
- 2) 02 5067 Set
- 3) 01 9204 Set
- 4) 05 1838
- 5) 14 0283 220 V 50 Hz bis FD 6504 14 0339 220 V 50 Hz ab FD 6505
- 6) 02 5606 Relais bis FD 6504 02 7377 Relais ab FD 6505





- 1) 08 3459
Set
- 2) 08 3460
Set

1) 01 9202

2) 11 0668
Set

3) 05 1287
Set

