





Libro de instrucciones
 (DE,GB,FR,IT,NL,SE,
 FI,NO,DK,ES,PT)
 52 2262

- 1) 16 5709
- 2) 16 5729
- 3) 16 5720
- 4) 16 5727
- 5) 16 9753
- 6) 35 2777



TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS		
Verdichter/Compressor/Compresseur/Compresor	DANFOSS	
Typ/Type/Tipo	TLES9K	
Förderleistung/Delivery/Debit/Aspiración l/h	1584	
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A	4,5	
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm	16,5	
Hi/aux.	16,9	
Temp.Reyler/Thermostat/Termostato	DANFOSS	
Typ/Type/Tipo	077B25	
Reglerstellung/Position/Conexión	Kalt Warm.	
Schaltwerte/Switching values/	-25° -17°	
Valeurs de commutation/Desconex.	-33° -23°	
(..abtaven' od)	-19,5° -13°	
Füllmenge/Fill. quantily/Charge/Carga R600a	g	40
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	90