






Libro de instrucciones
51 8644
(D,GB,F,E,I,P)





Pos.	ZEM	NECCHI
	GL45AB	ETR4
1	14 1598	14 1598
2	16 1618	16 1620
3	15 4887	16 0676
4	09 6836	16 0681
5		
6		
7	15 4915	15 4915
8	29 0214	29 0214
9	05 0166	05 0166
10		
11	26 3633	26 0931
12		
13		

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS

Verdichter/Compressor/Compresseur/Compresor Typ/Type/Tipo Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	ZEM GL45AB	NECCHI ETR4
---	---------------	----------------

Temp.Reyler/Thermostat/Termostato Typ/Type/Tipo Reglerstellung/Position/Conexión Schaltwerte/Switching values/ ..ein/conex.°C Valeurs de commutation/Desconex. ..aus"/descon. (..abtaven' od) ..alarm'	ATEA A03-0100 MIN – MAX. +4,5° +4,5° -16° -30°	
---	--	--

Füllmenge/Fill. quantity/Charge/Carga R134a	g	*	*
---	---	---	---

Anschlußwert/Comm. load/puiss. Connect./Potenc.	W		
---	---	--	--

Heizung/Heater/Chaufrage/Resistenc.descong. Widerstand/Resistance/Resistencia Leistung/Power/Puissance/Potencia	Ohm W		
---	----------	--	--

Ventilador/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	Ohm		
---	-----	--	--

Magnetventil/Magnetic valve/Electrovanne/Electrovalvula Widerstand/Resistance/Resistencia Spannung/Voltage/Tension/Tensión	Ohm V		
--	----------	--	--

Temp.Reyler/Thermostat/Termostato ambiente para ventilador refrigerador			
--	--	--	--

* Siehe Typenschild / See identification plate / Voir plaquette de caractéristiques / Ver plaqueta de características