






Gebrauchsanweisung
58 6356
(de,en)
Gebrauchsanweisung
58 6357
(fr,nl,it,es,el)
Montageanleitung
51 7991
(de,en,fr,nl,it,es,el)
Kochbuch
58 6292
(de,en,fr,nl,it,es)


Zubehör:

Dampfgarer
N8640X2


Bratrost engmaschig
Z1440X0
Bratrost gekröpft
Z1430X0
Backblech, Alu
Z1330X0
Backblech, email
Z1340X2
Bratenblech
Z1510X2
Brotbackstein
Z1910X0
Grillpfanne u. Bratrost
Z1230X2
Auflaufform
Z1270X2







- 1) 41 8562
- 2) 48 3856
kompl.
- 3) 15 5033
- 4) 41 8456
- 5) 17 1146



- 1) 41 8457
- 2) 18 9215
- 3) 41 9060
- 4) 41 9058
- 5) 18 9218
- 6) 43 2809
- 7) 18 9212
- 8) 41 8458