

**BOSCH**


T 445-0728144071-D1
T 445-0728144072-GB1
T 445-0728144073-CH1

WASCHGERÄTE
Trockner

Mat. - Nr. - Konstante
3740

Aufstellanweisung
51 0805/00
(D, I, F, NL, GB,
S, DK, N, SF)

Gebrauchsanweisung
51 1818/00
(D, I, F, NL, GB,
S, DK, N, SF)




**BOSCH**

T 445-0728144071-D1
T 445-0728144072-GB1
T 445-0728144073-CH1

WASCHGERÄTE
Trockner

Mat. - Nr. - Konstante
3740



**BOSCH**

T 445-0728144071-D1

T 445-0728144072-GB1

T 445-0728144073-CH1

WASCHGERÄTE
TrocknerMat. - Nr. - Konstante
3740