




Gebrauchsanweisung

58 8720
V01, V04
(de, en)
58 8736
V01, V04
(tr, el, ru)
58 8722
V02, V05
(nl, fr)
58 8724
V02, V05
(it, es, pt)
58 8723
V03, V06
(de, en)
59 1507
V07
(da, fi, no, sv)

Montageanleitung

58 8738

Kochbuch


58 8718
(de)
58 8719
(nl)
58 8744
(en)

1) 47 1818
V01-V03
V07
47 1820
V04-V06

HB86E760/01 – V01, Aluminium
 HB86E760N/01 – V02, Aluminium
 HB86E760B/01 – V03, Aluminium
 HB86E660/01 – V04, schwarz

HB86E660N/01 – V05, schwarz
 HB86E660B/01 – V06, schwarz
 HB86E760S/01 – V07, Aluminium


HERDE
 Einbaubacköfen



HB86E760/01 – V01, Aluminium
 HB86E760N/01 – V02, Aluminium
 HB86E760B/01 – V03, Aluminium
 HB86E660/01 – V04, schwarz

HB86E660N/01 – V05, schwarz
 HB86E660B/01 – V06, schwarz
 HB86E760S/01 – V07, Aluminium

HERDE
 Einbaubacköfen



HB86E760/01 – V01, Aluminium
 HB86E760N/01 – V02, Aluminium
 HB86E760B/01 – V03, Aluminium
 HB86E660/01 – V04, schwarz

HB86E660N/01 – V05, schwarz
 HB86E660B/01 – V06, schwarz
 HB86E760S/01 – V07, Aluminium

HERDE
 Einbaubacköfen

