






Gebrauchsanweisung  
58 4688  
(de)

Zubehör:

Back-u. Bratrost-  
engmasching  
Z1440X0  
Back-u. Bratrost  
gekröpft  
Z1430X0  
Backblech Alu  
Z1330X0  
Backblech Email  
Z1340X2  
Universalpfanne u.  
Bratrost  
Z1230X2



- 1) 18 2669  
V01  
18 2678  
V02  
18 2682  
V03
- 2) 18 2668  
V01  
18 2677  
V02  
18 2681  
V03



- 1) 18 2794  
V01  
18 3052  
V02  
18 2783  
V03
- 2) 17 2646
- 3) 18 2612  
V01  
18 2427  
V02, V03
- 4) 36 1788  
V01  
36 1920  
V02  
36 1923  
V03

1) 41 8562

